





## NOVITAL SPARE CIRCUITS

Product	Reference
1. Electronic circuit Covatutto mod.12 and mod.16	1100-0118
2. Electronic circuit Covatutto mod.24	1100-0119



## NOVITAL TURNING MOTORS

Product	Reference
1. Turning motor incubator mod.20/24/54	1100-03220
2. Turning motor incubator mod.40/120	1100-3222




## INCUBATOR CHASSIS TRAY

Product	Reference
Incubator chassis tray	1100-03801



## PLASTIC DIVIDER

Product	Reference
Plastic divider inc. mod. 20/24/54/120/108/162	1100-0390



## NOVITAL THERMOMETERS


Product	Reference
1. Thermometer Covatutto mod. 12/20 incubator	1100-0390
2. Thermometer inc. Covatutto mod. 7/16/24/54/108/162	1100-3222






## NOVITAL VENTILATORS

Product	Reference
1. Ventilator Covatutto mod. 20	1100-0310
2. Ventilator Covatutto mod. 24/54	1100-0311
3. Ventilator Covatutto mod. 120/108/162	1100-0300



## NOVITAL RESISTORS

Product	Reference
1. Resistencia recambio Covatutto mod. 20/40/120	1100-0330
2. Resistencia recambio Covatutto mod. 24/54/108/162	1100-0332
3. Chasis soporte y resistencia Covatutto 20	1100-0326



## FULL ELECTRIC SET

- Models 40/120/108/162 compatible.
- Complete set of spare parts or for auto construction of homemade incubator. It incorporates adjustable thermostat, interior light, heating system and complete ventilation.
- Recommended for upgrade models 40 or 120.
- Supply voltage 220V
- Average consumption 90w/h  
(*Thermometer not included.*)

Product	Reference
Full electric set	1100-01177

